

PRO FITNESS

335/7729(D)
MAGIC RIDER



CONTENTS


IMPORTANT SAFETY INFORMATION	1
EXPLODED-VIEW ASSEMBLY DIAGRAM	2
PARTS LIST	3
MAGIC RIDER PARTS CHECKING LIST	4
ASSEMBLY	5
EXERCISE INSTRUCTIONS	7
EXERCISE COMPUTER	8
TROUBLE SHOOTING	9
EXERCISE SESSION	10

IMPORTANT SAFETY INFORMATION

Please keep this manual in a safe place for easy reference.

1. It is important to read this entire manual before assembling and using the equipment.
Safe and effective use can only be achieved if the equipment is assembled, maintained and used properly. It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.
2. Before starting any exercise program you should consult your doctor to determine if you have any medical or physical conditions that could put your health and safety at risk, or prevent you from using the equipment properly. Your doctor's advice is essential if you are taking medication that affects your heart rate, blood pressure or cholesterol level.
3. Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, extreme shortness of breath, lightheadedness, dizziness, or feelings of nausea. If you do experience any of these conditions, you should consult your doctor before continuing with your exercise program.
4. Keep children and pets away from the equipment. The equipment is designed for adult use only.
5. Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 0.5 meters of free space all around it.
6. Before using the equipment, check that the nuts and bolts are securely tightened.
7. The safety of the equipment can only be maintained if it is regularly examined for damage and/or wear and tear.
8. Always use the equipment as indicated. If you find any defective components while assembling or checking the equipment, or if you hear any unusual noises coming from the equipment during use, stop immediately. Do not use the equipment until the problem has been rectified.
9. Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may get caught in the equipment or that may restrict or prevent movement.
10. The equipment has been tested and certified to EN957 under class H.C.
Suitable for home use only. Maximum weight of user is 100kg.
11. The equipment is not suitable for therapeutic use.
12. Care must be taken when lifting or moving the equipment so as not to injure your back. Always use proper lifting techniques and/or seek assistance if necessary.

EXPLODED-VIEW ASSEMBLY DRAWING




PARTS LIST

PART NO.	DESCRIPTION	QTY	PART NO.	DESCRIPTION	QTY
1.	Main frame	1	44.	Screw (ST4.2*25)	4
2.	Saddle support	1	45.	Screw (ST4.2*5)	6
3.	Pedal support	1	46.	Screw (ST4.2*10)	4
4A.	Front pedal support	2	47.	Screw (M6*16)	2
5.	Front connect tube	1	48.	Screw (M8*40)	6
6.	Middle connect tube	1	49.	Screw (ST4.2*25)	8
7.	Rear connect tube	1	50.	Flat washer (φ8)	11
8.	Bearing	1	51.	Big flat washer (φ6)	2
9.	Crank	1	52.	Curved washer (φ8)	8
10.	Front stabilizer	1	53.	Spring washer (φ6)	2
11.	Rear stabilizer	1	54.	Pin (φ8*36)	2
12.	Front handle bar	1	55.	Belt (J6)	1
13.	Rear handle bar	1	56.	Spring washer	1
14.	Axle	1	57.	Rectangle end cap	1
15.	Axle	1	58.	Belt wheel	1
16.	Fly wheel	1	59.	Rear pedal	2
17.	Computer support	1	60.	Front handle bar foam grip	1
18.	Bushing (φ25.4*φ10*8)	10	61.	Rear handle bar foam grip	1
19.	Bushing (φ24*φ19*φ15*8)	2	62.	Front pedal	2
20.	Bushing (φ24*φ19*φ12*8)	2	63.	End cap	2
21.	Bushing (φ25.4*φ22.4*φ15*8)	6	64.	Transport wheel	2
22.	pedal axle	2	65.	Saddle	1
23.	Fly wheel axle	1	66L.	Left chain cover	1
24.	Rear axle	1	66R.	Right chain cover	1
25.	Washer (φ25.4*3)	6	67.	Front sleeve	1
26.	Bolt (φ10*83.5)	3	68.	Rear sleeve	1
27.	Bolt (φ10*61.5)	1	69.	Stabilizer end cap	4
28.	Bolt (φ10*51.5)	1	70.	End cap	2
29.	Spring washer (φ17)	2	71.	End cap	2
30.	Spring washer (φ12)	2	72.	Computer	1
31.	Bearing	2	73.	Wire holder	1
32.	Bearing	2	74.	Sensor bracket	1
33.	Bolt (M6*60)	1	75.	Sensor wire	1
34.	Bolt (M6*82)	1	76.	Shelter	2
35.	Nut (M6)	4	77.	Computer screw	1
36.	Nut (M10)	2	78.	Magnetic	1
37.	Lock nut (M8)	8	79.	Screwdriver	1
38.	Screw (M8*20)	8	80.	Tool	1
39.	End Cap	2	81.	Adjustable foot cushion	2
40.	Screw (M8*35)	8	82.	Nut	2
41.	Bolt (M8*15)	1	83.	Washer	1
42.	Bolt (M6*15)	3	84.	Washer	1
43.	Screw (M6*16)	2			


MAGIC RIDER PARTS CHECKING LIST




MAIN FRAME*1




FRONT STABILIZER*1




REAR STABILIZER*1




LEFT FRONT PEDAL SET*1



RIGHT FRONT PEDAL SET*1



REAR PEDAL SET*2




COMPUTER*1



TOOL PACK*1

****Hardware might have already pre-assembled onto the components**



ASSEMBLY INSTRUCTIONS



STEP 1

Attach the front stabilizer (pt.10) and rear stabilizer (pt.11) to the main frame using four screws (M8*40)(pt.48).

REMARK: Please pay attention 4PCS screws fixed on the wood board are parts#48.




STEP 2

Attach the front pedal support (pt.4) to the main frame using two pins ($\phi 8 \times 36$)(pt.54).

Suggestion:

a. Height over 151cm b. Height below 150cm






STEP 3

Attach the rear pedals (pt. 59) by screwing them into the corresponding crank arm.



Note that the Right and Left pedal should be threaded on clockwise.



STEP 4

Connect the computer wire with sensor wire (pt.75) and slide the computer down to the computer bracket.

Then affix computer securely using the computer screw (pt.77).


REMARK: Please pay attention screw fixed on the computer.

EXERCISE INSTRUCTIONS

Using your **Magic Rider** regularly will provide you with several benefits. It will improve your physical fitness, tone your muscles and, in conjunction with a calorie-controlled diet, help you lose weight.


1. The Warm-Up Phase

This stage helps get the blood flowing around the body and the muscles working properly. It will also reduce the risk of cramp and muscle injury. It is advisable to do a few stretching exercises as shown below. Each stretch should be held for approximately 30 seconds. Do not force or jerk your muscles into a stretch - if it hurts, **STOP**.



2. The Exercise Phase

This is the stage where you put the effort in. After regular use, the muscles in your legs will become more flexible. Work at your own pace, but be sure to maintain a steady tempo throughout. The rate of work should be sufficient to raise your heartbeat into the target zone shown on the graph below.



This stage should last for a minimum of 12 minutes though most people start at about 15-20 minutes.

3. Cooling-Down Phase

This stage is to let your cardio-vascular system and muscles wind down. Slow down your tempo and work at this reduced level for about 5 minutes. Then repeat the stretching exercises, again remembering not to force or jerk your muscles into the stretch.

As you get fitter you may need to train longer and harder. It is advisable to train at least three times a week, and if possible to space your workouts evenly throughout the week.

EXERCISE COMPUTER



Functions and Operations

- **Batteries Installation**

Please install 1 AAA 1.5V battery in the battery compartment on the back of counter.
(Whenever battery is removed, all the functions values will be reset to zero.)

- **Auto On/Off**

When the user starts to exercise, the Display will show the workout value automatically. Once user stops using the equipment for more than 256 sec, the Display will turn off. But the workout value of count/ total count /cal will remain. When user continues on with the exercises again, workout value of count/ total count /cal will accumulate continuously.

※By pressing the button for 2 seconds, all the function values except T-COUNT will be reset to zero.

- **Auto Scan**

After the monitor is powered on or the button is pressed, the LCD will display all functions values from Time-Count- T-Count – Cal. Each value will be shown for 6 seconds.

- **Count**

Displays the step from 0 to 9999.

- **Total Count:**

Displays the total steps from 0 to 9999.

- **Time**

Displays the workout time from 00:00 to 99:59. User also can press the button to display the workout time value.

- **Calories**

Displays the calories consumption during training from 0.0 to 999.9. User also can press the button to display the calories consumption value.

TROUBLESHOOTING

1. Changing the battery.

To change the computer battery, please slide the computer from the computer bracket, remove the battery cover and remove the battery. Replace with 1 x AAA battery. Finally put the cover back, and slide the computer back on the computer bracket.

2. Computer not working correctly.

If your computer is not working correctly, please make sure the battery is installed correctly in the computer and that it is still working.

EXERCISE SESSION

Basic Position

Sit astride the saddle as if on a horse. Grip the handles with your hands to help stability and also grip the saddle using your inner thighs. Your feet should rest on the pedals.



To Start

Gently using your thighs and abdominal muscles and keeping your back straight, begin to slowly rock forwards and backwards. The **Magic Rider** will begin to gain momentum. It takes a bit of concentration and effort to maintain an even pace by using your torso and inner thighs.



Moving on

Once you have gained confidence you may wish to ride with your thighs gripping the saddle more tightly, allowing you to have your hands and arms free to increase the intensity of the ride.




Another position

Sitting 'side saddle' is another position that is worth trying, we only recommend this whilst holding quite firmly to the two handles.

By doing so, this riding action tones the abs, strengthens the inner thighs and torso muscles and works the lumbar muscles.

As the **Magic Rider** is self powered, you will be doing all the work yourself, so you'll benefit from a real workout !!

Enjoy.....



EXERCISE NOTES

Use this space to record your own exercise routine results

PRO FITNESS



Dimensions (L*W*H) 720 x 630 x 890 mm

Batteries 1 x AAA

Class Rating HC

Maximum User Weight 100KG

Please note that the specifications are subject to change without notice.

Retailer: ARG

Retailer address: 489-499 Avebury Boulevard
Saxon Gate West
Central Milton Keynes Bucks,
MK9 2NW